


ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

108218 Counter Height Table

REVISION 0 : 12/28/2018 REVISION 1 : 11/20/2019

PAGE 1 OF 4

COASTERFURNITURE.COM



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

15 MINUTES

PARTS IDENTIFICATION

ı

A	SIDE PANEL WITH EXTRA CLEAT		1PC	E LEAF		1PC
В	SIDE PANEL		2PCS	F LEG		4PCS
С	DOOR PANEL	0	1PC	G TOP F	PANEL	1PC
D	тор 🧲		1PC	н вотт	OM PANEL	1PC

HARDWARE IDENTIFICATION

1	HEX NUT (Ø5/16" x 1/2" - RBW)		4PCS	6	FLAT HEAD SCREW (Ø3.5 x 9/16" - RBW)	(1)	4PCS
2	BOLT (Ø1/4" x 1-9/16" - RBW)	()	14PCS	7	DOOR HINGE (120mm - RBW)		1PC
3	LOCK WASHER (Ø5/16" - RBW)		18PCS	8	ALLEN WRENCH (M4 x 59mm - RBW)		1PC
4	SMALL FLAT WASHER (Ø5/16" x 19mm - RBW)		14PCS	9	WRENCH (M4 x 50mm - RBW)		1PC
5	BIG FLAT WASHER (Ø5/16" x 22mm - RBW)		4PCS				


NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.


COASTER

ASSEMBLY INSTRUCTIONS


STEP 1




STEP 2



STEP 3




STEP 4






ASSEMBLY INSTRUCTIONS STEP 5




STEP 6 COMPLETE









Note: Dimension tolerance ±5%