

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

192728(B1&B2) Counter Height Table

REVISION 0 : 12/11/2019

PAGE 1 OF 4

COASTER

1PC

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

20 MINUTES

PARTS IDENTIFICATION

B1 (BOX 1)

A TOP

B HANDLE WITH SCREW 1SET

B2 (BOX 2)

C LEFT LEG 2PCS

D RIGHT LEG 2PCS

E DRAWER BOX 1PC

HARDWARE IDENTIFICATION

Z-B1 (BOX 1) - HARDWARE PACK IS LOCATED IN 192728 (B1)


1	ALLEN WRENCH (M4 - BLK)		1PC
2	SHORT BOLT (M6 x 40mm - RBW)		8PCS
3	LONG BOLT (M6 x 60mm - RBW)		8PCS
4	LOCK WASHER (M6 - RBW)	0	16PCS
5	FLAT WASHER (M6 - RBW)		16PCS
6	LEVELER (M6 X 23mm - BLK)		4PCS

PAGE 2 OF 4




ASSEMBLY INSTRUCTIONS


STEP 1




STEP 2



STEP 3




STEP 4




PAGE 3 OF 4



ASSEMBLY INSTRUCTIONS STEP 5



STEP 6



STEP 7 COMPLETE






PAGE 4 OF 4



INNER SIZE OF DRAWER: 14.84" X 17.28" X 2.56"



Note: Dimension tolerance ±5%