

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

222964 *Mirror*

PAGE 1 OF 3

REVISION 0: 10/03/2019

COASTERFURNITURE.COM

ITEM: 222964



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION

A MIRROR

DRESSER
*FROM BOX ITEM
#222963

C MIRROR SUPPORT
(PACKED WITH DRESSER)

2PCS

HARDWARE IDENTIFICATION

1 FLAT HEAD SCREW (M4 x 32mm - BLK) 8PCS


NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.


ITEM:222964



ASSEMBLY INSTRUCTIONS STEP 1



STEP 2 COMPLETE





COASTERFURNITURE.COM

ITEM:**222964**



