

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

REVISION 0 : 06/08/2018 REVISION 1 : 01/18/2019 REVISION 2 : 06/05/2019 REVISION 3 : 12/16/2019 REVISION 4 : 03/08/2020 911196 STORAGE BENCH

PAGE 1 OF13

COASTERFURNITURE.COM

COASTER*

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

\mathbb{N}

WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

60 MINUTES

PARTS IDENTIFICATION

Α	TOP	1PC	J TOP DRAWER FRONT PANEL	3PCS
В	LEFT SIDE	1PC	K TOP DRAWER LEFT SIDE PANEL	3PCS
С	RIGHT SIDE	1PC	L RIGHT SIDE PANEL	3PCS
D	UPPER SUPPORT BOARD	2PCS	M TOP DRAWER BACK PANEL	3PCS
E	MIDDLE SHELF PANEL	1PC	N TOP DRAWER BOTTOM PANEL	3PCS
F	LOWER SUPPORT BOARD	2PCS	O BOTTOM DRAWER FRONT PANEL	3PCS
G	BACK PANEL	1PC	P SIDE PANEL	6PCS
н	BASE LONG SIDE	2PCS	Q BOTTOM DRAWER BACK PANEL	3PCS
I	BASE SHORT SIDE	2PCS	R BOTTOM DRAWER BOTTOM PANEL	3PCS
NO	TE.		S BOTTOM PANEL	1PC

NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.


<u>Z</u>	HARDWARE IDENTIFICATION									
1	SHORT CAM BOLT (1/4 x 35mm - SR)		32PCS	9	SHORT BOLT (1/6 x 15mm - SR)		6PCS			
2	LARGE CAM LOCK (3/5 x11mm - SR)		28PCS	10	HANDLE (143 x 13x22mm-BLK)		3PCS			
3	LARGE CAM BOLT (1/4 x 70mm - SR)		4PCS	11	CAP (3/5 -WHT)	0	4PCS			
4	SMALL CAM LOCK (3/5 x 9MM - SR)		12PCS	12	SCREWDRIVER (4mm-SR)		1PC			
5	SMALL WOODEN DOWEL (1/3 x 30MM)		16 PCS	13	METAL BRACKET	٥	6PCS			
6	LARGE WOODEN DOWEL (1/3 x 50MM)		4PCS	14	WOOD SCREW (1/6 x 15mm - SR)	(1)	12 PCS			
7	WOOD SCREW (1/8 x 25mm - SR)	(+))	36PCS	15	LARGE BOLT (1/4 x 25mm - SR)		6PCS			
8	LARGE BOLT (1/4 x 40mm - SR)		4PCS							


NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.




ASSEMBLY INSTRUCTIONS STEP 1









ASSEMBLY INSTRUCTIONS STEP 3









ASSEMBLY INSTRUCTIONS









ASSEMBLY INSTRUCTIONS









ASSEMBLY INSTRUCTIONS STEP 9








COASTERFURNITURE.COM









ASSEMBLY INSTRUCTIONS

STEP 13



STEP 14




PAGE 10 OF 13

COASTERFURNITURE.COM

ITEM:911196 ASSEMBLY INSTRUCTIONS STEP 15









ASSEMBLY INSTRUCTIONS

STEP 17



STEP 18







PAGE 12 OF 13


COASTERFURNITURE.COM



ASSEMBLY INSTRUCTIONS STEP 19







Note: Dimension tolerance ±5%