

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

205294 *Mirror*

REVISION 0 : 05/10/2017 REVISION 1 : 02/05/2020

COASTERFURNITURE.COM

COASTER

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION

A MIRROR



1PC

C MIRROR SUPPORT (PACKED WITH MIRROR)

2PCS

B DRESSER FROM BOX ITEM #205293



1PC

HARDWARE IDENTIFICATION

1 SHORT BOLT (M6 x 35mm - BLK)



4PCS

FLAT WASHER 4 (1/4"ID x 19mm -BLK)



8PCS

2 LONG BOLT (M6 x 40mm - BLK)



4PCS

ALLEN 5 WRENCH (M4 x 60MM - BLK)



1PC

B LOCK WASHER (1/4" - BLK)




8PCS




ASSEMBLY INSTRUCTIONS

STEP 1






STEP 2





ASSEMBLY INSTRUCTIONS

STEP 3




STEP 4 COMPLETE





COASTERFURNITURE.COM





Note : Dimension tolerence ± 5%