



ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

509482
LOVESEAT

REVISION 0:04/12/2020

ITEM :509482



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1.Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING !

- 1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2.This product is for home uses only and not intended for commercial establishments.



ASSEMBLY TIME

20 MINUTES

PARTS IDENTIFICATION

A



LOVESEAT

1PC

B



LEG

4PCS

HARDWARE IDENTIFICATION


1	SCREW	 M6*20MM	12PCS
2	ALLEN KEY	 M6	1PC

ITEM:509482





ASSEMBLY INSTRUCTIONS


STEP1



STEP2



ITEM: 509482



Note : Dimension tolerance $\pm 5\%$