

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

723448
SOFA TABLE

ITEM : 723448

ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

- 1.Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store
- 2.This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION


HARDWARE

A TOP



1PC

B BASE



1PC

1 SILICONE GASKET




4PC


ITEM : 723448

ASSEMBLY INSTRUCTIONS



STEP 1





STEP 2



STEP 3





COASTERFURNITURE.COM

Note: Dimension tolerance $\pm 5\%$