

**ASSEMBLY INSTRUCTIONS**  
**COASTER FINE FURNITURE**



*Fine Furniture for every stage of life*

**SOFA TABLE**

**723449**

ITEM : 723449

**ASSEMBLY INSTRUCTIONS**


**ASSEMBLY TIPS:**

- 1.Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



**WARNING!**

- 1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store
- 2.This product is for home use only and not intended for commercial establishment.



**ASSEMBLY TIME**

**10 MINUTES**

**PARTS IDENTIFICATION**


**HARDWARE**

**A TOP**




**1PC**

**B BASE**



**1PC**

**1 BOLT 8X35MM**




**4PC**

**2 WASHER φ20X2MM**



**4PC**

**3 ALLEN KEY 30X80MM**




**1PC**


ITEM : 723449

ASSEMBLY INSTRUCTIONS



STEP 1





STEP 2



STEP 3





COASTERFURNITURE.COM

Note: Dimension tolerance  $\pm 5\%$