



## ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

**505817**  
**SOFA**

REVISION 0: 6/20/2019  
5/21/2020

PAGE 1 OF 4

COASTERFURNITURE.COM

ITEM : 505817



# ASSEMBLY INSTRUCTIONS


## ASSEMBLY TIPS:

- 1.Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



### WARNING!

- 1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2.This product is for home use only and not intended for commercial establishment.




ASSEMBLY TIME

10 MINUTES

## PARTS IDENTIFICATION


A SOFA 1 PC




B LEGS 4 PCS




C PLASTIC WASHER 4 PCS




D SEAT CUSHION 2 PCS




E PILLOW 2 PCS




ITEM : 505817  
ASSEMBLY INSTRUCTIONS  
STEP 1



STEP 2



STEP 3



STEP 4

