



*ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE*



**601921
MOTION SOFA**

ITEM: 601921

ASSEMBLY INSTRUCTIONS



ASSEMBLY INSTRUCTION

ASSEMBLY TIPS:

- 1.Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

⚠ WARNING!

- 1.Don't attempt to repair or modify parts that are broken or defective.Please contact the store immediately.
- 2.This product is for home use only and not intend for commercial establishment.



ASSEMBLY TIME PER UNIT: 15MINUTES

PARTS IDENTIFICATION

A		BASE	1PC
B		LEFT BACK	1PC
C		MIDDLE BACK	1PC
D		RIGHT BACK	1PC
E		LEFT EAR	1PC
F		RIGHT EAR	1PC

ITEM: 601921

ASSEMBLY INSTRUCTIONS



STEP 1

STEP 2

STEP 4

STEP 5

STEP 5

STEP 6

A


A

A

A

A

A



Note : Dimension tolerance $\pm 5\%$