


ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

193162 Parson Chair

ITEM: 193162

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

15 MINUTES

PARTS IDENTIFICATION

A BACK FRAME 1PC C FRONT LEG 2PCS

B SEAT CUSHION WITH FRAME 1PC

HARDWARE IDENTIFICATION

1	LONG BOLT (5/16" x 3-1/2"-RBW)	(humumumumum	4PCS	4 L	OCK WASHER (5/16"-RBW)	9PCS
2	SHORT BOLT (5/16" x 2-1/4"-RBW)		5PCS	. 5	FLAT WASHER /16" x 22mm-RBW)	9PCS
3	ALLEN WRENCH (5 mm-RWB)		1PC		VOOD DOWEL Ø10 x 30mm-WOOD)	2PCS

NOTE:

Quantities shown are for one chair.


Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: **193162**


ASSEMBLY INSTRUCTIONS

COASTER


STEP 1




STEP 2



STEP 3



STEP 4 COMPLETE






PAGE 3 OF 4

COASTERFURNITURE.COM

ITEM: **193162**





Note: Dimension tolerance ±5%

COASTERFURNITURE.COM