



ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

500607
OTTOMAN

ITEM : 500607



ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

- 1.Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



WARNING!


- 1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2.This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

5 MINUTES

PARTS IDENTIFICATION



HARDWARE IDENTIFICATION

A OTTOMAN



1PC

B FEET



4PCS


Z	HARDWARE PACKAGE		
NO	DESCRIPTION	FIGURE	QTY
1	LONG BOLT $\frac{5}{16}$ " * 3"		4PCS

ITEM : 500607


ASSEMBLY INSTRUCTIONS





STEP 1




STEP 2



STEP 3



500607



Note: Dimension tolerance $\pm 5\%$

