



ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

505656
OTTOMAN

ITEM : 505656



ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

- 1.Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



WARNING!



- 1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store
- 2.This product is for home use only and not intended for commercial establishment.




ASSEMBLY TIME

5 MINUTES

PARTS IDENTIFICATION




A OTTOMAN



1PC

B SEAT CUSHION




1PC

C FOOT




4PCS




STEP 1



STEP 2




STEP 3



505656

COASTER
FINE FURNITURE



Note: Dimension tolerance $\pm 5\%$

