



*ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE*



Fine Furniture for every stage of life

**509073
CHAIR**

REVISION 0: 06/18/2020
REVISION 1: 07/20/2020

COASTERFURNITURE.COM

PAGE 1 OF 4

ITEM: 509073

ASSEMBLY INSTRUCTIONS




ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.







WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME 20 MINUTES

PARTS IDENTIFICATION


A		CHAIR	1PC
B		BACK CUSHION	1PC
C		LEG	4PCS
D		WASHER	8PCS

ITEM: 509073




ASSEMBLY INSTRUCTIONS


STEP 1





STEP 2




STEP 3



STEP 4



ITEM: 509073



Note : Dimension tolerance $\pm 5\%$

COASTERFURNITURE.COM