

# ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

REVISION 0: 07/07/2020

881281(B1&B2) Executive Desk

### **ASSEMBLY INSTRUCTIONS**



### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



### **WARNING!**

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediatelly.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

25 MINUTES

# **PART IDENTIFICATION**

B1 (BOX 1)

**UNIVERSAL KEY** 

A	ТОР	1PC
<b>B2</b>	(BOX 2)	
В	LEFT COMPARTMENT	1PC
С	RIGHT COMPARTMENT	1PC
D	CENTER PANEL	1PC
E	LEG	8PCS
F	DRAWER HANGER	4PCS
G	BIG DRAWER DIVIDER	4PCS
Н	SMALL DRAWER DIVIDER	4PCS

PAGE 2 OF 7

COASTERFURNITURE.COM

2SETS

### **ASSEMBLY INSTRUCTIONS**



### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



### **WARNING!**

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediatelly.
- 2. This product is for home use only and not intended for commercial establishments.

## HARDWARE IDENTIFICATION

### Z-B2 (BOX 2) - HARDWARE PACK IS LOCATED IN 881281(B2)

1	SHORT BOLT (M6 x 40mm - BLK)		14PCS
2	LONG BOLT (M6 x 100mm - BLK)		16PCS
3	LOCK WASHER (1.6 x 14mm - BLK)		30PCS
4	FLAT WASHER (1 x 18mm - BLK)		30PCS
5	ALLEN WRENCH (M4 x 65mm - BLK)		1PC
6	FLAT HEAD SCREW (4 x 38mm - BLK)	< <i>111111111111</i> (%)	16PCS
7	WOOD DOWEL (10 x 30mm - BRW)		4PCS


### NOTE:


Philips head screw driver is required in the assembly process; however, manufacturer does not provide this item.


# **ASSEMBLY INSTRUCTIONS**

# STEP 1











# ITEM: 881281(B1&B2) **ASSEMBLY INSTRUCTIONS** STEP 5






PAGE 6 OF 7

COASTERFURNITURE.COM





INNER SIZE OF DRAWER (A): 14.4"W x 17.8"D x 1.8"H
INNER SIZE OF DRAWER (B): 14.4"W x 17.8"D x 3"H
INNER SIZE OF DRAWER (C): 14.4"W x 17.8"D x 9.6"H
INNER SIZE OF DRAWER (D): 24.9"W x 10.7"D x 1.8"H



**NOTE:** Dimension tolerance ± 5%