

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

902867
SNACK TABLE

REVISION 0 : 09/25/2017
REVISION 1 : 08/12/2020

ITEM:902867



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!


1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.

ASSEMBLY TIME 20 MINUTES

PARTS IDENTIFICATION

A


TOP GLASS



1PC

B

SUPPORT PANEL



1PC

C

SUPPORT LEG



3PCS

HARDWARE IDENTIFICATION

1

SCREW
(#8 x 21mm BLK)



6PCS

3

CAP
(ϕ 10mm)



6PCS

2

BOLT
(1/4" x 15mm BLK)



3PCS

4

ALLEN WRENCH
(4mm)




1PC


ITEM:902867
ASSEMBLY INSTRUCTIONS




STEP 1 Do not tighten until each step is completed or instructed.




STEP 2



ITEM:902867
ASSEMBLY INSTRUCTIONS
STEP 3





STEP 4
COMPLETE



ITEM:902867 ASSEMBLY INSTRUCTIONS



Product Size : 400 DIA X 540 H (MM)
Product Size : 15 $\frac{3}{4}$" DIA X 21 $\frac{1}{4}$"



Note : Dimension tolerance $\pm 5\%$