

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life



REVISION 0 : 01/25/2018 REVISION 1 : 05/31/2018 REVISION 2 : 08/10/2018 REVISION 3 : 07/09/2019 REVISION 4 : 12/14/2020

PAGE 1 OF 14

COASTERFURNITURE.COM

ITEM:800999




ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

WARNING! 1. Don't attem 2. This produce

Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
This product is for home use only and not intended for commercial establishments.



Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

PAGE 2 OF 14

ITEN	/l: 80099	9			COA	STER	
SN	MIDDLE DRAWER FRONT PANEL		1 PC	A1N	MIDDLE DRAWER BOTTOM PANEL	FINE FL	1 PC
TN	MIDDLE DRAWER BACK PANEL		1 PC	B1N	DRAWER SUPPORT		1 PC
UN	MIDDLE LEFT DRAWER SIDE PANEL		1 PC	C1N	METAL FRAME		2 PCS
VN	MIDDLE RIGHT DRAWER SIDE PANEL		1 PC				

z HARDWARE IDENTIFICATION												
NO	DESCRIPTION	FIGURE	Q'TY	NO	DESCRIPTION	FIGURE	Q'TY					
1	GLUE 40g	C C C	1 PC	8	SCREW FOR RAIL Ø 3.5x12mm SR	() and ()	40 PCS					
2	WOODEN DOWEL Ø 8x30mm		38 PCS	9	KNOB	\bigcirc	4 PCS					
3	CAM BOLT Ø 7x35.5mm SR	and the	20 PCS	10	KNOB BOLT Ø 4x28mm BLK		4 PCS					
4	CAM LOCK Ø 15x12mm SR		20 PCS	11	BOLT M 6x20mm BLK	(0) U	24 PCS					
5	LONG SCREW Ø 4.5x42mm SR	autur C	19 PCS	12	ALLEN WRENCH 4mm SR		1 PC					
6	SCREW Ø 4.3x35mm SR	AND DESCRIPTION OF THE OWNER OF T	17 PCS	13	STICKER Ø 20mm		4 PCS					
7	RAIL L = 350mm SR	(L)	4 SET									

Z7 not included in blister packaging.

NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

PAGE 3 OF 14

