



*ASSEMBLY INSTRUCTIONS*  
*COASTER FINE FURNITURE*



*Fine Furniture for every stage of life*

**609543P**  
**Power Glider Recliner**

ITEM : 609543P

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1.Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



**WARNING!**



- 1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2.This product is for home use only and not intended for commercial establishment.




ASSEMBLY TIME

2 MINUTES

**PARTS IDENTIFICATION**



- A BACK
- B BASE
- C LEFT EAR
- D RIGHT EAR
- E PLUG-IN POWER SUPPLY




ITEM : 609543P


ASSEMBLY INSTRUCTIONS




STEP 1




STEP 2





STEP 3



STEP 4



# 609543P



Note: Dimension tolerance  $\pm 5\%$