




ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

509361
SOFA

ITEM: **509361**

ASSEMBLY INSTRUCTIONS




ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

5 MINUTES


PARTS IDENTIFICATION

	FIGURE	PART NAME	QUANTITY
A		BASE	1PC
B		SEAT CUSHION	3PCS
C		LEG	4PCS
D		MIDDLE LEG	1PC
E		PILLOW	2PCS


ITEM: 509361

ASSEMBLY INSTRUCTION



STEP 1



STEP 2




STEP 3



ITEM: 509361

COASTER

FINE FURNITURE



Note : Dimension tolerance $\pm 5\%$