



*ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE*



Fine Furniture for every stage of life

**509781
SOFA**

REVISION 0: 12/12/2020

COASTERFURNITURE.COM

PAGE 1 OF 4

ITEM: 509781

ASSEMBLY INSTRUCTIONS




ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME 20 MINUTES


PARTS IDENTIFICATION

A		BASE	1PC
B		SIDE BACK CUSHION	2PCS
C		MIDDLE BACK CUSHION	1PC
D		LEG	4PCS
E		PILLOW	2PCS
F		MIDDLE LEG	1PC


ITEM: 509781
ASSEMBLY INSTRUCTIONS




STEP 1





STEP 2




STEP 3



STEP 4



ITEM: 509781



Note : Dimension tolerance $\pm 5\%$

COASTERFURNITURE.COM