

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life



REVISION 0 : 09/28/2017 REVISION 1 : 12/28/2020

COASTERFURNITURE.COM

PAGE 1 OF 6



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.

2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

20 MINUTES

PARTS IDENTIFICATION

Α	FRONT PANEL	<u>[[]]]]]]]]]]]]]]]]]]]</u>]]]]]]]]]]]]]]]]	1PC	G	LEFT BOTTOM PANEL		1PC
в	BACK PANEL	<u></u>	1PC	н	DIVIDER		1PC
С	LEFT SIDE PANEL WITH CASTER		1PC	I	BOTTOM RAIL	[=]	4PCS
D	RIGHT SIDE PANEL WITH CASTER		1PC	J	CENTER BOTTOM RAIL	<u> </u>	2PCS
Е	CENTER BOTTOM PANEL		3PCS	к	CASTER	Æ	4PCS
F	RIGHT BOTTOM PANEL		1PC	x	KNOB WITH SCREW		4SETS


HARDWARE IDENTIFICATION

1	LONG BOLT (1/4 x 60mm Φ 12 - SR)		4PCS	5	HALF ROUND NUT (1/4 x 22mm - SR)	\bigcirc	4PCS
2	SHORT BOLT (1/4 x 30mm Φ 12 - SR)		4PCS	6	WOOD DOWEL (8 x 30mm)		2PCS
3	LONG FLAT HEAD SCREW (4 x 35mm - SR)	().	16PCS	7	SHORT FLAT HEAD SCREW (4 x 15mm - SR)		8PCS
4	WOOD RAIL (20 x 45 x 50mm)	9	2PCS	8	ALLEN WRENCH (4 x 58MM - SR)		1PC


NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.














STEP 5















STEP 8




STEP 9 COMPLETE





COASTERFURNITURE.COM



COASTERFURNITURE.COM