



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

360150
Sofa Bed

REVISION 0 : 05/24/2019
REVISION 1 : 01/29/2021

ITEM: **360150**



ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

30 MINUTES

PARTS IDENTIFICATION

A SOFABED



1PC

C ARM



2PCS

B LEGS



4PCS

HARDWARE IDENTIFICATION


Z01

PLASTIC WASHER
(50 x 2mm - RBW)




4PCS

STEP 1



STEP 2



ITEM: 360150



ASSEMBLY INSTRUCTIONS

PRODUCT DIMENSION (Note: Dimension tolerance $\pm 5\%$)

