

**ASSEMBLY INSTRUCTIONS**  
**COASTER FINE FURNITURE**



*Fine Furniture for every stage of life*

**953242**

**SOFA TABLE**

ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

- 1.Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2.This product is for home use only and not intended for commercial establishment.



ASSEMBL TIME 10 MINUTES

PARTS IDENTIFICATION


HARDWARE

A TOP




1PC

B BASE



1PC

1 BOLT 8X35MM




4PCS

2 WASHER φ20X2MM








4PCS

3 ALLEN KEY 30X80MM



1PC





COASTERFURNITURE.COM

Note: Dimension tolerance  $\pm 5\%$