



ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

500682
Loveseat

ITEM: **500682**

COASTER
FINE FURNITURE

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.

PARTS IDENTIFICATION:

- | | | | |
|----|--------------------|--|------|
| A. | LOVESEAT | | 1 PC |
| B. | FRONT LEG | | 2 PC |
| C. | REAR LEG | | 2 PC |
| D. | LEFT SEAT CUSHION | | 1 PC |
| E. | RIGHT SEAT CUSHION | | 1 PC |



ASSEMBLY TIME 20 MINUTES

HARDWARE PACKAGE

NO	DESCRIPTION	FIGURE	SIZE	QTY
1	BOLT		5/16"x3"	2PCS
2	SMALL FLAT WASHER		5/16"x1.0MM	2PCS
3	BIG FLAT WASHER		3/8"x1.0MM	4PCS
4	SPRING WASHER		3/8"	4PCS
5	SPANNER		M5	1PC
6	WRENCH			1PC



