

## ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



*Fine Furniture for every stage of life*

**306055**  
***Daybed***

# ITEM: 306055



## ASSEMBLY INSTRUCTIONS


### ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



### WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

60 MINUTES

## PARTS IDENTIFICATION

A-LSF HEADBOARD LEG



1PC

B- RSF HEADBOARD LEG



1PC

C-LSF FOOTBOARD LEG



1PC

D- RSF FOOTBOARD LEG




1PC

E-HEADBOARD



2PCS

F- BACK FRAME




1PC

G-DAYBED RAIL




2PCS

H-TRUNDLE LONG RAIL



2PCS

I-TRUNDLE SHORT RAIL



2PCS

J-SLAT



42PCS

K-SLAT CONNECTOR



84PCS

L-FINIAL



4PCS

M-LOCK WHEEL



2PCS

N- WHEEL



2PCS

O-SLAT SPACER



21PCS

## HARDWARE IDENTIFICATION

### Z - HARDWARE

1 BOLT( Ø 1/4"x16MM)



24PCS

3 ALLEN WRENCH(1/4")



1PC

2 BOLT( Ø 1/4"x55MM)



4 PCS

4 OPEN WRENCH(1/4")




1PC

ITEM: 306055


ASSEMBLY INSTRUCTIONS




STEP 1




STEP 2



STEP 3



STEP 4




ITEM: 306055


ASSEMBLY INSTRUCTIONS




**STEP 5**




**STEP 6**



**STEP 7**



**STEP 8**




ITEM: **306055**



## ASSEMBLY INSTRUCTIONS



### STEP 9



### STEP 10



Note : Dimension tolerance  $\pm 5\%$

