


ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

700910
TV Console

ITEM: 700910(B1-B2)



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



Warning !!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishment.




ASSEMBLY TIME

30 MINUTES

PARTS IDENTIFICATION


B1(BOX1)

(A) TOP PANEL




1 PC

(B) BOTTOM PANEL




1 PC

(C) BACK FEET SLAT



1 PC


(D) BACKBOARD



1 PC


B2(BOX2)

(E) LEFT SIDE PANEL




1 PC

(G) MID PARTITION




1 PC

(F) LEFT PARTITION



1 PC

(H) RIGHT PARTITION













1 PC

ITEM: 700910(B1-B2)



PARTS IDENTIFICATION

(I) RIGHT SIDE PANEL		1 PC	(O) RIGHT DRAWER SIDE PANEL		2 PCS
(J) MOVABLE SHELF		2 PCS	(P) DRAWER BOTTOM		2 PCS
(K) FIXED SHELF		2 PCS	(Q) LEFT DRAWER FRONT		1 PC
(L) DOOR		2PCS	(R) RIGHT DRAWR FRONT		1 PC
(M) DRAWER BACK		2 PCS			
(N) LEFT DRAWER SIDE PANEL		2 PCS			

ITEM: 700910(B1-B2)



HARDWARE IDENTIFICATION

Z-B2(BOX2)-HARDWARE PACK IS LOCATED IN 700910(B2)


1	LARGE CAMBOLT	L=29mm		28PCS
2	LARGE CAMLOCK	Ø15mm		32PCS
3	SMALL CAMBOLT	L=20mm		8PCS
4	SMALL CAMLOCK	Ø12mm		8PCS
5	WOOD DOWEL	Ø8X25mm		24PCS
6	LARGE SCREW	Ø4X30mm		8PCS
7	SMALL SCREW	Ø4X16mm		24PCS
8	SHELF PIN			8PCS
9	DOUBLE END CAMBOLT	L=74mm		2PCS
10	SMALL HANDLE			2PCS
11	LARGE HANDLE			2PCS
12	HANDLE SCREW	M4X20mm		6PCS
13	HEX SOCKET SCREW	M8X25mm		3PCS
14	ALLEN WRENCH	M5		1PC
15	STICKER	Ø22mm		32PCS
16	BACK PANEL BUCKLE			8PCS
17	EXTRA SMALL SCREW	Ø3X14mm		8PCS
18	HINGE			4PCS
19	LEG	Ø38X60mm		3PCS
20	GLUE			1PC
21	GLIDES	Ø12"		4SETS
22	EXTRA SMALL SCREW	Ø3.5X12mm		24PCS

ITEM: 700910(B1-B2)


ASSEMBLY INSTRUCTIONS



STEP 1



STEP 2




ITEM: 700910(B1-B2)


ASSEMBLY INSTRUCTIONS



STEP 3



STEP 4




ITEM: 700910(B1-B2)


ASSEMBLY INSTRUCTIONS



STEP 5



STEP 6




ITEM: 700910(B1-B2)


ASSEMBLY INSTRUCTIONS



STEP 7




STEP 8




ITEM: 700910(B1-B2)

ASSEMBLY INSTRUCTIONS

STEP 9



STEP 10




ITEM: 700910(B1-B2)


ASSEMBLY INSTRUCTIONS



STEP 11



STEP 12




ITEM: 700910(B1-B2)


ASSEMBLY INSTRUCTIONS



STEP 13



STEP 14




ITEM: 700910(B1-B2)


ASSEMBLY INSTRUCTIONS



STEP 15



STEP 16



ITEM: 700910(B1-B2)

DIMENSION

