



*ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE*



Fine Furniture for every stage of life

**551643
OTTOMAN**

REVISION 0: 12/06/2021

COASTERFURNITURE.COM

PAGE 1 OF 4

ITEM: 551643

ASSEMBLY INSTRUCTIONS




ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!


- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME 15 MINUTES

PARTS IDENTIFICATION


A



OTTOMAN

1PC

B



LEG


4PCS

ITEM: 551643




ASSEMBLY INSTRUCTIONS



STEP 1




STEP 2



STEP 3



ITEM: 551643



Note : Dimension tolerance $\pm 5\%$

COASTERFURNITURE.COM