

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

724258 Coffee Table

COASTERFURNITURE.COM

ITEM: 724258

ASSEMBLY INSTRUCTIONS




ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

15 MINUTES

PARTS IDENTIFICATION

A TOP



1PC

B LEG




4PCS


TEM:**724258**

COASTER


ASSEMBLY INSTRUCTIONS STEP 1



STEP 2




STEP 3 COMPLETE



COASTERFURNITURE.COM



INNER SIZE OF DRAWER: 20"X15.5"X4"



Note: Dimension tolerance ±5%