

*ASSEMBLY INSTRUCTIONS*  
*COASTER FINE FURNITURE*



*Fine Furniture for every stage of life*

**724317**  
**End Table**

ITEM: **724317**



## ASSEMBLY INSTRUCTIONS

### ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



### WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

10 MINUTES

## PARTS IDENTIFICATION

A TOP 1PC




B LEG FRAME 2PCS



## HARDWARE IDENTIFICATION

1 BOLT (M8 x 25mm - BLK) 4PCS



2 FLAT WASHER (M10 x 16mm - BLK) 4PCS




3 ALLEN WRENCH (5mm - BLK) 1PC




ITEM: **724317**




**ASSEMBLY INSTRUCTIONS**  
**STEP 1**




**STEP 2**



**STEP 3**  
**COMPLETE**



ITEM:724317



Note : Dimension tolerance  $\pm 5\%$