ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE

Fine Furniture for every stage of life

801410
Gaming Desk

ITEM:**801410**

## ASSEMBLY INSTRUCTIONS

COASTER®
FINE FURNITURE

ASSEMBLY TIPS:
1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

⚠️ **WARNING !**
1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishment.

| ASSEMBLY TIME | 45 MINUTE |

PARTS IDENTIFICATION

A	LEFT SIDE FRAME	1PC	G	SHELF SUPPORT TUBE	3PCS
B	RIGHT SIDE FRAME	1PC	H	BACK SUPPORT	2PCS
C	LEFT SUPPORT FRAME	1PC	I	LEFT SLIDE	1PC
D	RIGHT SUPPORT FRAME	1PC	J	RIGHT SLIDE	1PC
E	LOWER CROSSBAR	1PC	K	KEYBOARD BRACKET	4PCS
F	UPPER CROSSBAR	1PC	L	SUPPORT BRACKET	2PCS

NOTE:
Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

COASTERFURNITURE.COM

ITEM:**801410**

PARTS IDENTIFICATION

M	HOOK		3PCS
N	STOPPER		2PCS
O	CUP HOLDER		1PC
P	TRAY BOARD		2PCS

Q	TOP SHELF BOARD		1PC
R	DESK TOP		1PC
S	KEYBOARD		1PC
T	POWER PORT WITH USB		1PC

HARDWARE IDENTIFICATION

1	BOLT (1/4"x1-3/16" - BLK)		10PCS
2	BOLT (1/4"x1/2" - BLK)		8PCS
3	BOLT (3/16"x1/2" - BLK)		42PCS
4	BOLT (3/16"x1/4" - BLK)		4PCS
5	BOLT (5/32"x3/4" - BLK)		4PCS
6	SCREW (M4x25mm - BLK)		6PCS
7	SCREW (M4x15mm -BLK)		4PCS

8	SCREW (M4x13mm - BLK)		2PCS
9	NUT (∅3/16" - BLK)		5PCS
10	WASHER (∅16mm - BLK)		10PCS
11	WASHER (∅12mm - BLK)		57PCS
12	ALLEN WRENCH (4x22x60mm - BLK)		1PC
13	WRENCH		1PC

NOTE:
Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM:**801410**

## ITEM:**801410**

ASSEMBLY INSTRUCTIONS

| 2	🔩	**8PCS**
12	⌐	

STEP 1:

ASSEMBLY
Do not fully tighten all bolts until assembly is complete.
This will help all parts to assemble properly.

STEP 2:

1	🔩	**6PCS**
10	⊙	**6PCS**
12	⌐	

COASTERFURNITURE.COM

ITEM:**801410**

STEP 3:

A

B

1   **4PCS**
10   **4PCS**
12

1
10

STEP 4:

K

3   **8PCS**
11   **8PCS**

3
11

ITEM:**801410**

STEP 5:

4	🔩	4PCS
9	⬡	4PCS
13	🔧	

J

I

5-1

9

4

9

4

5-2

STEP 6:

7	🔩	4PCS
11	⊙	4PCS

S

FRONT

7
11

7
11

COASTERFURNITURE.COM

ITEM:**801410**

STEP 7:

3	5PCS
9	1PC
11	6PCS
13	

H

UP

11   3

9   11

11   3

STEP 8:

3	18PCS
11	18PCS

O

M

L

M

M

L

11   3

COASTERFURNITURE.COM

ITEM:**801410**

STEP 9:

5		4PCS
11		4PCS

N

P

N

P

11

5

11

5

11

5

11

5

STEP 10:

3		8PCS
11		8PCS

11   3

COASTERFURNITURE.COM

ITEM:**801410**

STEP 11:

| 8 | 🔩 | **2PCS** |

STEP 12:

| 6 | 🔩 | **6PCS** |
| 11 | ⊙ | **6PCS** |

COASTERFURNITURE.COM

ITEM:801410

STEP 13:

11
3

STEP 14:

COASTERFURNITURE.COM

ITEM:**801410**

1510mm(59.4")

635mm(25")

865-965mm(34"~38")

762mm(30")

635mm(25")

Note : Dimension tolerance ±5%