

## ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

192075 <u>Dining Chair</u>



#### **ASSEMBLY INSTRUCTIONS**

#### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

10 MINUTES

### **PARTS IDENTIFICATION**

A CABINET



1PC

B LEG



4PCS

C ADJUSTABLE SHELF



2PCS

#### NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

#### **ASSEMBLY INSTRUCTIONS**



#### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### **WARNING!**

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

10 MINUTES

### **HARDWARE IDENTIFICATION**

1 ALLEN KEY (4MM) 1PC

2 ALLEN SCREW (M6\*45)



8PCS

3 MESON (Φ6\*16\*1.2)




8PCS

#### NOTE:


Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

# ASSEMBLY INSTRUCTIONS STEP 2

STEP 1



Remove adjustable shelf and install foot



# STEP 3 COMPLETE

The mirror part provided in this package is not a tempered mirror.

Please handle with care. Mirror part may explode.

