

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

111101 DINING TABLE

ITEM:111101 (B1-B3)



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

\triangle

WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

10

PARTS IDENTIFICATION

B1 (BOX 1)

B3 (BOX 3)

A TOP MARBLE 1PCS

D LEG FRAME



2PCS

B2 (BOX 2)

B TOP FRAME 1PCS

C BASE



1PCS

NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM:111101 (B1-B3)

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.

HARDWARE IDENTIFICATION

Z-B2 (BOX 2) - HARDWARE PACK IS LOCATED IN 111101 (B3)

1 ALLEN WRENCH 1PCS

2 SHORT BOLT (M8*55mm) 20PCS


3 FLAT WASHER D20*2 20PCS

4 FRAME REST 8PCS

Hardware pack is located in 111101 B3

NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.






COASTERFURNITURE.COM

ITEM:111101 (B1-B3)





Note: Dimension tolerance ±5%