


ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

509181
Sofa

ITEM:509181



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1.Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

Warning !!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishment.




ASSEMBLY TIME

25 MINUTES

PARTS IDENTIFICATION


A
SOFA



1 PC


B

BACK CUSHION



3 PCS


C
LEG



4 PCS

D

MIDDLE LEG



1 PC

ITEM: **509181**



HARDWARE IDENTIFICATION


1	ALLEN SCREW		8pcs
2	SCREW		16pcs
3	ALLEN WRENCH		1pc

ITEM: **509181**


ASSEMBLY INSTRUCTIONS



STEP 1



STEP 2




ITEM: **509181**

ASSEMBLY INSTRUCTIONS



STEP 3



STEP 4

