

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

511131
Sofa

ITEM: 511131

ASSEMBLY INSTRUCTIONS




ASSEMBLY TIPS:

- 1.Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2.This product is for home use only and not intended for commercial establishment.




ASSEMBLY TIME

6 MINUTES


PARTS IDENTIFICATION

CEÁÁ ÓCEÙÒ




1 PC

E LEG



4 PCS

ÓÁÜÖP VÁBACK CUSHION




1 PC

F MIDDLE LEG




1 PC

ÔÁŦ ÖÖŠÒÁBACK CUSHION



1 PC


ÖÁLEFTÁBACK CUSHION



1 PC

HARDWARE IDENTIFICATION

1 ALLEN SCREW



16pcs

2 ALLEN WRENCH




1pc



ITEM: **511131**

ASSEMBLY INSTRUCTIONS



STEP 1



STEP 2



STEP 3



Note: Dimension tolerance $\pm 5\%$

