

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

51113'
7\ Ujf

ITEM:511133

ASSEMBLY INSTRUCTIONS




ASSEMBLY TIPS:

- 1.Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2.This product is for home use only and not intended for commercial establishment.




ASSEMBLY TIME

6 MINUTES

PARTS IDENTIFICATION

A BASE




1 PC

B BACK CUSHION



1 PC


C LEG



4 PCS

HARDWARE IDENTIFICATION

1 ALLEN SCREW



16pcs

2 ALLEN WRENCH




1pc

ITEM: **511133**





ASSEMBLY INSTRUCTIONS



STEP 1



STEP 2



STEP 3



Note: Dimension tolerance $\pm 5\%$

