

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

801504 WRITING DESK

REVISION 0: 09/20/2017 REVISION 1: 07/13/2022

PAGE 1 OF 4

COASTERFURNITURE.COM

ITEM:801504 ASSEMBLY INSTRUCTIONS




ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME 25 MINUTES

PARTS IDENTIFICATION


А	TOP GLASS						1PC
В	SIDE FRAME						4PCS
С	TOP CROSSBAR						2PCS
D	BOTTOM CROSSBAR						2PCS
HARDWARE IDENTIFICATION							
1	CAP (\$2")	②	4PCS	4	SUCTION CUP (8mm)	9	4PCS
2	LONG BOLT (1/4" x 50mm SR)	~	4PCS	5	LEVELER (1/4" x 18mm)	.	8PCS
3	SHORT BOLT (1/4' x 15mm SR)	8	8PCS	6	ALLEN WRENCH (4mm)		1PC

ITEM:801504 ASSEMBLY INSTRUCTIONS




STEP 1

Do not tighten until each step is completed or instructed.



STEP 2



COMPLETE




COASTERFURNITURE.COM

ITEM:801504 ASSEMBLY INSTRUCTIONS



Product Size: 1500 X 800 X 776 H (MM)

Product Size : 59" X 31 $\frac{1}{2}$ " X 30 $\frac{1}{2}$ "



Note: Dimension tolerance ±5%