

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

509921 SOFA

REVISION 0: 14/07/2022

COASTERFURNITURE.COM

PAGE 1 OF 4

ITEM: 509921

ASSEMBLY INSTRUCTIONS

COASTER*


ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.




WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME 15 MINUTES

PARTS IDENTIFICATION



В



LEG

4PCS

С




MIDDLE LEG

1PCS


Z HARDWARE PACKAGE


NO	DESCRIPTION	FIGURE	Q'TY
(1)	SHORT BOLT	9mmm	16PCS
	⊄8MM*35MM		
(2)	ALLEN		1PCS
	WRENCH ⊄		
	6MM		











Note: Dimension tolerance ±5%

COASTERFURNITURE.COM