



## ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

**509171**

**SOFA**

REVISION 0: 03/11/2022  
REVISION 1: 07/18/2022

PAGE 1 OF 4

COASTERFURNITURE.COM

ITEM : 509171



# ASSEMBLY INSTRUCTIONS


## ASSEMBLY TIPS:

- 1.Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



### WARNING!





- 1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2.This product is for home use only and not intended for commercial establishment.




ASSEMBLY TIME

10 MINUTES


## PARTS IDENTIFICATION

A	SOFA		1PC
B	LEG		4PCS
C	PLAIN PILLOW		2PCS
D	PATTERNED PILLOW		2PCS


ITEM : 509171  
ASSEMBLY INSTRUCTIONS  
STEP 1




STEP 2



STEP 3



ITEM : 509171



NOTE: Dimension tolerance  $\pm 5\%$

