



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

509191

SOFA

ITEM : 509191

ASSEMBLY INSTRUCTIONS




ASSEMBLY TIPS:

- 1.Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2.This product is for home use only and not intended for commercial establishment.




ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION

A


SOFA



1PC

B

LEG



4PCS



C

MIDDLE LEG




1PC


ITEM : 509191
ASSEMBLY INSTRUCTIONS
STEP 1




STEP 2



STEP 3



ITEM : 509191



NOTE: Dimension tolerance $\pm 5\%$

