


ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

753434
3PC Occasional Sets

ITEM:753434



ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

- 1.Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



Warning !!




1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

30 MINUTES













PARTS IDENTIFICATION



ITEM: **753434**



HARDWARE IDENTIFICATION


1	STICKER	Ø45mm		12PCS
2	FULL THREADED ROD	M8x70mm		12PCS
3	DOWEL	Ø8X25mm		24PCS
4	JAM WASHER	Ø8mm		12PCS
5	NUT	M8mm		12PCS
6	OPEN WRENCH	M14mm		1PC
7	METAL ALLEN BOLT	M6X65mm		12PCS
8	METAL BARREL NUT	Ø10x15mm		12PCS
9	WASHER	Ø16X2mm		12PCS
10	ALLEN WRENCH	M4mm		1PC
11	STICKER	Ø13mm		12PCS
12	GLUE			1PC

ITEM: **753434**


ASSEMBLY INSTRUCTIONS



STEP 1




STEP 2




ITEM: **753434**

ASSEMBLY INSTRUCTIONS

STEP 3




STEP 4




ITEM: **753434**

ASSEMBLY INSTRUCTIONS

STEP 5



STEP 6



ITEM: **753434**

DIMENSION

