

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

115101(B1&B2) *Dining Table*

REVISION 0: 10/27/2021



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.





15 MINUTES

PARTS IDENTIFICATION

B1 (BOX 1)

TOP



1PC

В **LEG**



4PCS

B2 (BOX 2)

C LAZY SUSAN

(4MM - RBW)



1PC

BASE D



1PC

HARDWARE IDENTIFICATION

Z-B1(BOX 1) - HARDWARE PACK IS LOCATED IN 115101(B1)

1	BOLT (Ø5/16" x 2-1/4" - RBW)	16PCS
2	LOCK WASHER (Ø5/16" - RBW)	16PCS
3	FLAT WASHER (Ø5/16" - RBW)	16PCS
4	ALLEN WRENCH	1BC


PAGE 2 OF 5

COASTERFURNITURE.COM


1PC



ASSEMBLY INSTRUCTIONS STEP 1




STEP 2




COASTER

ASSEMBLY INSTRUCTIONS STEP 3




STEP 4




COASTER

ASSEMBLY INSTRUCTIONS STEP 5



STEP 6 COMPLETE




PAGE 5 OF 5

COASTERFURNITURE.COM



Inner Size of Drawer: 16.25"W X 9.75"D X 5.00"H X 0.25"T



Note: Dimension tolerance ±5%