



ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

551594
Armless Chair

ITEM: 551594

ASSEMBLY INSTRUCTIONS




ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

8 MINUTES

PARTS IDENTIFICATION


	PART NAME	FIGURE	QUANTITY
A	CHAIR BASE	A line drawing of a chair base, which is a rectangular box with a slightly raised backrest and a horizontal line across the middle.	1PC
B	PILLOW	A line drawing of a diamond-shaped pillow with a slightly irregular, hand-drawn outline.	2PCS
C	LEG	A line drawing of a chair leg, which is a rectangular block with a small, cylindrical foot at the bottom.	4PCS

ITEM: 551594




ASSEMBLY INSTRUCTIONS


STEP 1 Turn over the item and take out the legs from zippered pouch and install the legs as pictures show



STEP 2 Please remove the wood block with screwdriver, do not use a hammer




STEP 3 Rotate the metal clips, put the chair and corner closer





STEP 4 Insert the metal clips to connect other units as pictures show

COMPLETE



ITEM: 551594



Note : Dimension tolerance $\pm 5\%$

