

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

115551
DINING TABLE

ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

- 1.Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store
- 2.This product is for home use only and not intended for commercial establishment.





ASSEMBLY TIME

10 MINUTES


PARTS IDENTIFICATION

HARDWARE



A	GLASS TOP		1PC
B	BASE		1PC



1	SUCTION CUP		4PC
---	-------------	---	-----

ITEM : 115551
ASSEMBLY INSTRUCTIONS
STEP 1



STEP 2





Note: Dimension tolerance $\pm 5\%$

COASTERFURNITURE.COM