

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

115561 DINING TABLE

ITEM: 115561

ASSEMBLY INSTRUCTIONS




ASSEMBLY TIPS:

- 1.Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store
- 2. This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION

HARDWARE

A GLASS TOP



1PC

1 SUCTION CUP

6PC

B BASE



1PC

PAGE 2 OF 4


COASTERFURNITURE.COM

ITEM: 115561


ASSEMBLY INSTRUCTIONS








STEP 2




COASTERFURNITURE.COM

ITEM: 115561







COASTERFURNITURE.COM