

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

300629 (B1-B2) DAY BED

REVISION 0 : 05/01/2019 REVISION 1 : 07/12/2019 REVISION 2 : 08/01/2019 REVISION 3 : 08/31/2022

ITEM:300629 (B1-B2)

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1.Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME 30

30 MINUTES

PARTS IDENTIFICATION

B1: (BOX 1) A LEFT SIDE		1PC
B RIGHT SIDE		1PC
B2: (BOX 2)	\searrow	
С васк		1PC
D FRONT RAIL		1PC
E METAL FRAME		1PC
F FRONT PANEL		1PC
G SLATS		12PCS
H WHEEL		2PCS

WHEEL WITH LOCK

STOPPER

HARDWARE IDENTIFICATION:

COASTER

Z-B2 (BOX 2) - HARDWARE PACK IS LOCATED IN 300629 (B2)

	1		
NO	DESCRIPTION	FIGURE	QTY
1	LARGE BOLT 5/16X1.5"-BLK	O TIME TO THE STATE OF THE STAT	6PCS
2	MEDIUM BOLT 5/16X1"-BLK	TIME	8PCS
3	SMALL BOLT 1/4X0.63"-BLK	D	24PCS
4	FLAT WASHER 5/16"-BLK	0	14PCS
5	SMALL ALLEN WRENCH 1/4"-SLV		1PC
6	BIG ALLEN WRENCH 5/16"-SLV		1PC
7	WRENCH 5/16"-SLV	>	1PC

2PCS


2PCS

ITEM:300629(B1-B2)


ASSEMBLY INSTRUCTIONS









step2



ITEM:300629 (B1-B2) ASSEMBLY INSTRUCTIONS step3







ITEM:300629 (B1-B2)
ASSEMBLY INSTRUCTIONS
step5



