



*ASSEMBLY INSTRUCTIONS*  
*COASTER FINE FURNITURE*



*Fine Furniture for every stage of life*

720229  
**SOFA TABLE**

REVISION 0 : 09/12/2017  
REVISION 1 : 11/03/2022

PAGE 1 OF 4

COASTERFURNITURE.COM

ITEM: 720229



# ASSEMBLY INSTRUCTIONS


## ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.







## WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.







ASSEMBLY TIME 50 MINUTES

## PARTS IDENTIFICATION

A	TOP GLASS		1PC
B	SHELF GLASS		2PCS
C	SIDE FRAME		2PCS
D	CROSSBAR		6PCS


## HARDWARE IDENTIFICATION

1	BOLT (1/4" x 12mm BLK)		12PCS	3	CAP (25 x 25mm BLK)		4PCS
2	SUCTION CUP (9mm)		18PCS	4	ALLEN WRENCH (4mm)		1PC




# ITEM: 720229 ASSEMBLY INSTRUCTIONS



**STEP 1** Do not tighten until each step is completed or instructed.



## STEP 2




# ITEM: 720229 ASSEMBLY INSTRUCTIONS



**Product Size : 1200 X 400 X 813 H (MM)**

**Product Size : 47.25" X 15.75" X 32"**



Note : Dimension tolerance  $\pm 5\%$