


ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

935871
SNACK TABLE

REVISION 0: 25/04/2020

REVISION 1 : 11/08/2022

PAGE 1 OF 4

COASTERFURNITURE.COM

ITEM: 935871



ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.





ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION

HARDWARE IDENTIFICATION




ITEM: 935871

ASSEMBLY INSTRUCTIONS




STEP 1



ITEM: 935871

ASSEMBLY INSTRUCTIONS



Note : Dimension tolerance $\pm 5\%$