




## ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



*Fine Furniture for every stage of life*

**190721**  
**7PC Dining Set**

ITEM: **190721**

## ASSEMBLY INSTRUCTIONS

### ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



### WARNING!






1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.












ASSEMBLY TIME

15 MINUTES

## PARTS IDENTIFICATION


A	TABLE TOP		1PC
B	TABLE LEG		4PCS
C	BACK FRAME		6PCS
D	SEAT CUSHION WITH FRAME		6PCS
E	FRONT LEG		12PCS

## HARDWARE IDENTIFICATION


1	<b>BOLT 3</b> ( Ø5/16" x 2-1/4" - RBW )		8PCS	6	<b>BOLT 1</b> ( Ø1/4" x 1-1/2" - RBW )		6PCS
2	<b>BIG LOCK WASHER</b> ( Ø5/16" - RBW )		8PCS	7	<b>SMALL LOCK WASHER</b> ( Ø1/4" - RBW )		54PCS
3	<b>BIG FLAT WASHER</b> ( Ø5/16" - RBW )		8PCS	8	<b>SMALL FLAT WASHER</b> ( Ø1/4" - RBW )		54PCS
4	<b>BOLT 4</b> ( Ø1/4" x 3-1/4" - RBW )		24PCS	9	<b>ALLEN WRENCH</b> ( 4MM - RBW )		7PCS
5	<b>BOLT 2</b> ( Ø1/4" x 2-1/4" - RBW )		24PCS				

ITEM: **190721**

**ASSEMBLY INSTRUCTIONS**  
**STEP 1**




**STEP 2**




ITEM: **190721**

**ASSEMBLY INSTRUCTIONS**


**STEP 3**




**STEP 4**



**STEP 5**  
**COMPLETE**




ITEM: 190721



Note: Dimension tolerance  $\pm 5\%$

ITEM: **190721**



Note: Dimension tolerance  $\pm 5\%$