

# ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

193132 Parson Chair

# ITEM: **193132**

### **ASSEMBLY INSTRUCTIONS**



#### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### WARNING


- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

15 MINUTES

## PARTS IDENTIFICATION



### **HARDWARE IDENTIFICATION**

1	LONG BOLT (5/16" x 3-1/2"-RBW)	{hamanamanananananananananananananananana	4PCS	4 LOCK WASHER (5/16"-RBW)	9PCS
2	SHORT BOLT (5/16" x 2-1/4"-RBW)		5PCS	5 FLAT WASHER (5/16" x 22mm-RBW)	9PCS
3	ALLEN WRENCH (5 mm-RBW)		1PC	6 WOOD DOWEL (Ø10 x 30mm-WOOD)	2PCS

#### NOTE:

Quantities shown are for one chair.


Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

# ITEM: **193132**


### **ASSEMBLY INSTRUCTIONS**

# COASTER


## STEP 1




## STEP 2



## STEP 3




# STEP 4 COMPLETE



PAGE 3 OF 3

# ITEM: **193132**





Note: Dimension tolerance ±5%