


ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

193168 Counter Height Stool

REVISION 0: 06/01/2020

PAGE 1 OF 3

COASTERFURNITURE.COM

ITEM: 193168

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

15 MINUTES

PARTS IDENTIFICATION

Δ BACK FRAME



1PC

D SIDE STRETCHER



2PCS

B SEAT CUSHION WITH FRAME



1PC

E FRONT STRETCHER



1PC

C FRONT LEG



2PCS

HARDWARE IDENTIFICATION

1	LONG BOLT (5/16" x 3-1/2"-RBW)	(humumumumumu)	4PCS
2	SHORT BOLT (5/16" x 2-1/4"-RBW)	(Junumumuv	5PCS
3	ALLEN WRENCH (5 mm-RBW)		1PC
4	LOCK WASHER (5/16"-RBW)		9PCS

5 FLAT WASHER (5/16" x 22mm-RWB)



9PCS

6 WOOD DOWEL (Ø10 x 30mm-WOOD)



2PCS

7 FLAT HEAD SCREW (Ø8 x 1-3/4"-RWB)



6PCS

NOTE:

Quantities shown are for one stool.


Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: 193168


ASSEMBLY INSTRUCTIONS

COASTER


STEP 1




STEP 2



STEP 3



STEP 4 COMPLETE






PAGE 3 OF 3

ITEM: 193168





Note: Dimension tolerance ±5%